### CC-113 - Motor circuit breaker



**Spare Part Number:** CC-113

Net Weight: 0.00kg

**Net Dimensions:** 0.00cm x 0.00cm x 0.00cm

**Technical Datasheet:** Protected Link

#### **Description**

### **CC-113 Motor circuit breaker**

#### **Equipment Ref**

EVO 3 ELF Ref. QP1 for Water Pump (P1) only when DH-006 is used.

EVO 3 EDLF Ref. **QP1** for Water Pump (P1) only when DH-006 is used, **QExh** for Dryer exhaust blower.

Easy to Plate EVO 3 IP D Ref. **QVD1, QVD2, QVD3, QVD4** for air circulation blowers (Dryer)

EVO 4 DLF Ref. **QV1** - for Blower serving Dryer drawers 1 and 2, **QV2** - for Blower serving Dryer drawers 3 and 4, **QV3** - for Blower serving Dryer drawers 5 and 6, **QV4** - for Dryer exhaust (V4)

EVO 4 iP Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used.

Easy to Plate EVO 4 iP D Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used (Processor) - **QV1**, **QV2**, **QV3**, **QV4** for air circulation blowers (Dryer) - **QV5**, for air exhaust blowers (Dryer)

Easy to Plate EVO 4 iP I Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used (Processor) - **QV1**, **QV2**, **QV3**, **QV4** for air circulation blowers (Dryer) - **QV5**, for air exhaust blowers (Dryer)

EVO 5 DLF Ref. **QV1** - for Blower serving Dryer drawers 1 and 2, **QV2** - for Blower serving Dryer drawers 3 and 4, **QV3** - for Blower serving Dryer drawers 5 and 6, **QV4** - for Dryer exhaust (V4)

EVO 5 IP Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used.

Easy to Plate EVO 5 IP D Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used (Processor) - **QV1**, **QV2**, **QV3**, **QV4** for air circulation blowers (Dryer) - **QV5**, for air exhaust blowers (Dryer)

Easy to Plate EVO 5 IP I Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used (Processor) - **QV1**, **QV2**, **QV3**, **QV4** for air circulation blowers (Dryer) - **QV5**, for air exhaust blowers (Dryer)

EVO 5 BP Ref. QP5 for Heating/Cooling Liquid Pump (P5) only when DH-006 is used.

Easy to Plate EVO 5 BP D Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used (Processor) - **QV1**, **QV2**, **QV3**, **QV4** for air circulation blowers (Dryer) - **QV5**, for air exhaust blowers (Dryer)

Easy to Plate EVO 5 BP I Ref. **QP5** for Heating/Cooling Liquid Pump (P5) only when DH-006 is used (Processor) - **QV1**, **QV2**, **QV3**, **QV4** for air circulation blowers (Dryer) - **QV5**, for air exhaust blowers (Dryer)

# 812 Ref. **QF**

# Catalogues/Families

Suitable for the following equipment models:	
EVO 3 EDLF	
EVO 3 ELF	
EVO 4 D	
EVO 4 DLF	
EVO 4 E	
EVO 4 EDLF	
EVO 4 EDLF	
EVO 4 ELF	
EVO 5 D	
EVO 5 DLF	
EVO 5 E	
EVO 5 ELF	
Spare Part Type	
Electrical Component	
Spare Part Group	
Circuit Breaker	
Stock Type	
Standard Stock	